



Einhell

CLASSIC



Cordless Angle Grinder

TC-AG 18/115 Li - Solo

Item No.: 4431130

Ident No.: 11017

Bar Code: 4006825628746

The Einhell cordless angle grinder TC-AG 18 Li – Solo for sanding/cutting/polishing is the lightest angle grinder of its class. For safety there is a softstart function & restart safeguard. The overload cut-out, robust alu gear housing & modified air guidance contribute to a longer service life. For comfortable operation the motor and gearing are separated, resulting in very smooth operation; the tool is of slimline design with ergonomic soft grip surfaces. The handle can be fitted in three positions. It is also a member of the Power X-Change family: the same rechargeable battery for all PXC devices. For optimum results a 2.6 Ah Plus battery or higher is recommended. The battery, charger & cutting disc are available separately.

Features & Benefits

- Member of the Power X-Change family
- Lightest angle grinder of its class
- Softstart function and restart safeguard to make it safer to use
- Overload cut-out for a long service life
- Modified air guidance for better cooling and longer service life
- Very smooth operation thanks to separation of motor and gearing
- Robust aluminium gear housing
- Slimline design with ergonomic softgrip
- Additional handle can be fitted flexibly in 3 positions
- Recommendation for optimum results: 2.6 Ah Plus battery & higher
- Supplied without battery and charger (available separately)
- Supplied without cutting disk




Technical Data

- Size of grinding wheel cover 115 mm
- No-load speed (idle speed) Max. 8500 min⁻¹
- Max. cutting depth 28 mm

Logistic Data

- Product weight (kg) 1.21
- Gross weight (kg) 2.05
- Dimensions single packaging 290 x 142 x 108 mm
- Pieces per export carton 6 Pieces
- Gross weight of export carton 13.4 kg
- Dimensions Export Carton 440 x 310 x 252 mm
- Container quantity (20"/40"/40"HC) 4914 | 10206 | 11340



Available as special accessories



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory