






Parts List



Intel Installation Guide




AMD Installation Guide




Installation Guide


1




2



3




4




5

Intel




or

AMD




LCD Display Setup Guide

1



2



CAUTION


To control the LCD display by TT RGB PLUS Software, Please connect the water block and motherboard with cable P.

MB SYNC Installation Guide


CAUTION

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

1



2



The specifically designed clip could ensure the cable is connected properly

3

